



# Surface Cleanliness of Hydrothermally Grown Zinc Oxide Microparticles for Antibacterial Usage

Vivek Athipatla

Dustin Johnson and Dr. Yuri M. Strzhemechny




1. Zinc Oxide - Properties
2. Zinc Oxide - Antibacterial Pathways
3. Unmet Needs
4. Microparticles vs Nanoparticles
5. Hypothesis and Purpose
6. Materials and Methods
7. SEM Results and Analysis
8. FTIR Results and Analysis
9. Conclusions
10. Future Directions

- Zinc oxide (ZnO) is an important multifunctional material with broad applications in many fields.
- ZnO possesses many excellent properties, and its synthesis is simple.
- Furthermore, zinc is a necessary element of our health and has high biocompatibility with human cells, low toxicity, and good antimicrobial activity.
- All these properties allow for the usage of ZnO materials in medicine as biomarkers, drug carriers, and therapeutic.




Raha S et al, *Nanoscale Adv.*, 2022



- Despite the promise of ZnO nanoparticles, it is currently used only as barrier creams (diaper rash) and sunscreens
- One hindrance to wider adoption is that most fundamental physical and chemical mechanisms driving growth inhibition are not well understood
- Nature of interactions between ZnO surfaces and extracellular material is not clear
- Hence, deeper investigations hold important theoretical and practical value.



- We focus on two forms of ZnO: Microparticles and Nanoparticles - Both have comparable antibacterial properties
- However, microparticles are preferred due to their larger size and distinct surface types
- Surface cleanliness is also very influential for antibacterial interactions.
- The goal of this research is to discover if there are significant differences in surface cleanliness between ZnO micro-scale particles and commercial ZnO nano-scale particles that are causing imperfections in the research process.



Samadi M et al, *Research on Chemical Intermediates*, 2022




## Purpose

Examine the surface cleanliness of ZnO microparticles vs commercial nanoparticles utilizing Scanning Electron Microscopy (SEM) and Fourier Transform Infrared Spectroscopy (FTIR)

## Hypothesis


There are no significant differences in the surface cleanliness of the microparticles compared to nanoparticles

- Used both ZnO nanoparticles as well as microparticles
- The nanoparticles were purchased from Sigma Aldrich and ZoChem
- ZnO microparticles were synthesized through a bottom-up, hydrothermal growth method.






- SEM is a type of microscope that produces a magnified image of a sample by using electrons
- These electrons are scattered as they penetrate the surface of the sample
- The energies of these scattered electrons are collected to produce a final image of the sample
- SEM was used to see if there were any glaring surface or structural differences between the nano and microparticles






Schematic representation of SEM. ThermoFisher Scientific

## Commercial Nanoparticles




- Homogeneity of the microparticles stands in contrast to the heterogeneity of the nanoparticles in these pictures
- This affirms the current knowledge that microparticles have well-defined polar and nonpolar surfaces and are more useful for conducting antibacterial research

## Microparticles




- FTIR spectroscopy is a technique which allows for characterization of functional groups at the material surface
- Attenuated Total Reflection (ATR) is the most widely used form of FTIR
- Infrared (IR) beams send light through the crystal and is attenuated as it penetrates the sample.
- FTIR measures the energy loss at different wavelengths which allows us to identify the presence of surface functional groups




Alessio A., et. al. Biomedical Spectroscopy and Imaging 4 (2015)

- Functional groups are simply molecules attached to the surface
- FTIR is used to find and discern these functional groups
- Finding these functional groups helps to determine the surface cleanliness of the microparticles which may affect their interactions with bacteria



# Composite FTIR Plot Results



- Peaks represent where a specific functional group is located.
- The nanoparticles and microparticles practically have the same FTIR spectrum
- Microparticles exhibit lower absorbance due to their larger size
- Only difference is a benign “O-H Bending” group at the 1400 cm<sup>-1</sup> region.



- SEM images show that microparticles have much more distinct polar and nonpolar surfaces as well as highly homegenous crystals
- There exist no significant structural differences in the surface contamination between micro and nanoparticles based on FTIR spectra
- Better and more accurate results can be obtained because of the benefits that microparticles provide in comparison to nanoparticles
- Larger sizes of the microparticles as well as distinct polar and nonpolar faces helps in better identifying the point of surface interactions with bacteria



- ZnO microparticles can be the catalyst for massive improvements in antibacterial research and applications
- Plan to continue this work by collaborating with the biology department at Texas Christian University to study ZnO-bacteria interactions at the microparticle surface



Dr. Yuri M. Strzhemechny  
Associate Professor and Chair  
Department of Physics and Astronomy  
Texas Christian University



Dustin Johnson  
Graduate Student  
Department of Physics and Astronomy  
Texas Christian University





- Babayevska, N., Przysiecka, Ł., Iatsunskiy, I. et al. ZnO size and shape effect on antibacterial activity and cytotoxicity profile. *Sci Rep* 12, 8148 (2022). <https://doi.org/10.1038/s41598-022-12134-3>
- Jin, S. E., & Jin, H. E. (2021). Antimicrobial Activity of Zinc Oxide Nano/Microparticles and Their Combinations against Pathogenic Microorganisms for Biomedical Applications: From Physicochemical Characteristics to Pharmacological Aspects. *Nanomaterials* (Basel, Switzerland), 11(2), 263. <https://doi.org/10.3390/nano11020263>
- Samadi M, et al (2019) Design and tailoring of one-dimensional ZnO nanomaterials for photocatalytic degradation of organic dyes: a review. *Research on Chemical Intermediates*, DOI:10.1007/s11164-018-03729-5
- Raha S, Md Ahmaruzzaman ZnO nanostructured materials and their potential applications: progress, challenges and perspectives, *Nanoscale Adv.*, 2022,4, 1868-1925
- Nanakoudis, A What is SEM? Scanning Electron Microscopy Explained 11.14.2019 <https://www.thermofisher.com/blog/materials/what-is-sem-scanning-electron-microscopy-explained/>
- Ausili, Alessio & Sánchez, Marina & Gómez-Fernández, Juan. (2015). Attenuated total reflectance infrared spectroscopy: A powerful method for the simultaneous study of structure and spatial orientation of lipids and membrane proteins. *Biomedical Spectroscopy and Imaging*. 4. 159-70. 10.3233/BSI-150104. [https://doi.org/10.1016/S0304-4157\(99\)00004-0](https://doi.org/10.1016/S0304-4157(99)00004-0)